

## 1 Preparation

Unplug cable of battery charger, then plug red battery cut-off plug into the machine.

Fill solution tank with clean water.  
Or: use the J-Flex system to fill the tank with cleaning solution.

Dose cleaning product into dosing aid and pour into the grey fresh water tank.

Mount squeegee: position pockets of the squeegee exactly under the squeegee holder and push holder down.

Position tool(s) carefully under lifted brush unit.

## 6 Operation

Switch on machine with the button on the display – press button for 3 seconds.

Lower brush unit with the foot pedal. Briefly pull the operating lever for brush drive to allow coupling of tool.

Lower squeegee by pushing down the foot pedal.

Start vacuum motor and solution supply (press orange buttons)  
“ECO” button: lowers the suction motor for use in noise sensitive area.

Adjust solution flow with the light blue lever on the left side of the machine.

## Maintenance

Clean the floor.  
After that switch off the machine with the key switch.

Drain recovery tank with the draining hose, then drain the solution tank with the hose on the back-side of the machine.

Rinse the recovery tank with fresh water. To do so it can be removed from the machine.

Clean the floater and the yellow dirt sieve.

Clean solution filter.

Lift brush unit and remove tool by turning anti-clockwise, clean tools and allow to air dry.

Remove and clean squeegee.

Wipe machine with moist cloth.

Flip the yellow dirt sieve and store the machine with partially open lid for ventilation (lid rests on the yellow dirt sieve).

Unplug the red battery cut-off plug, then plug in the cable of the battery charger.

