

Before use/ Preparation



1 Display warning signs.



2 Check equipment, especially plug and cable. Report any fault or damage to a supervisor.



3 Do not plug in until machine is ready for use.




4 Tip machine back to put handle on floor. Place pad centered onto pad drive and secure it with the pad fixation. Raise machine back upright.



5 Insert dust bag and ensure that opening jumps over the suction tube locking element (the bulge).




6 Close dust bag compartment with the cover and check correct fitting of the suction hose.



7 Connect power cable to mains socket. Unlatch the foot pedal and slowly lower the pad (working position).



8 Squeeze lower lever. Adjust handle position so operator's back is straight with arms lightly bent. Release lever to lock in position.



9 Raise the handle upwards to go right and lower the handle to go left. Raise right – lower Left.



10 Switch the machine on by pressing the main 'ON/OFF' switch.



11 To activate the machine press the orange safety button and squeeze the lever.



12 Commence polishing at closest point to the plug socket with cable behind you at all times.



13 Hold cable over handle in your hand, NOT over shoulder.



14 Keep cable out of the tool and flat on the floor, NOT taut.



15 Work with overlapping parallel passes forward and backward.



16 Check pad regularly for clogging and to ensure that the holder fixation is secure. Unplug machine and turn/change pad as required.

End of operation



17 Press the foot pedal down to lock into place (tool up – parking position).



18 Put handle in upright position when not in use. Unplug if left unsupervised.



19 When changing socket, coil cable from machine to plug, not plug to machine, to avoid twisting.



20 Switch the machine off by pressing the main 'ON/OFF' switch and unplug.



21 Wind cable back into handle and cord hook, wiping clean with a damp cloth as you do.



22 Tip machine back to put handle on floor. Remove the pad fixation and the pad. Replace the pad fixation onto the pad drive.



23 Check the dust bag and exchange it as required. Whip machine clean with a damp cloth.



24 Vacuum up dust and foreign bodies off the pad. Do not tumble dry the pads!

ATTENTION!
Before use please ensure that you have read and understood the instruction booklet supplied with the equipment.
The machine must not remain stationary while the engine is running. This could damage the floor like other incorrect operation.

The pad rotates at 2.000 rpm. Only use approved tools.
Never use the machine without a dust bag fitted. Always wear appropriate Personal Protection Equipment (PPE). Always observe appropriate Health and Safety procedures.



25 Store machine.

Questions: 1-800-558-2332